

#### Directions for Use



### Disinfect to Protect

- > When placing a new MicroClave on a catheter, disinfect the catheter hub and prime the MicroClave.
- > Before accessing a MicroClave, always disinfect the injection site with the approved antiseptic per facility protocol.
- > Scrub the injection site in accordance with facility protocol for appropriate scrubbing and dry times.



# Administer or Aspirate

- > Attach IV tubing, syringe or blood tube holder to MicroClave by inserting the luer and twisting ½ turn, or until a friction fit is achieved.
- > Do not over-tighten a luer beyond the friction fit as this may damage both the luer and the MicroClave.
- > To disconnect, grasp MicroClave and then twist mating luer away from MicroClave until loose. Do not hold catheter hub during disconnect as this may cause accidental removal of MicroClave from hub.



## Flush After Each Use

- > Flush the MicroClave with normal saline or in accordance with facility protocol. After blood use, the MicroClave can be flushed clean and does not require change-out.
- > Use routine flushing in accordance with facility protocol in order to maintain catheter patency.
- Change MicroClave in accordance with facility protocol and CDC Guidelines.

### **Functional Attributes**

- › Lipid and Blood Compatible
- Radiographic Imaging Compatible (CT Compatible)
- Contains No Latex, Phthalate's (DEHP) or Metal Components, MRI Compatible





© 2012 ICU Medical Inc. M1-1305 Rev. 03