

- Made from incinerable polyethylene film, removes foot borne particulate before entering the cleanroom
- Seamless one-piece construction
- Numbered tabs provide easy identification and sheet separation
- Easy mobility for carts and wheeled machinery
- Polyethylene film contains a special anti-microbial agent providing long-lasting protection against bacterial growth

Colors: Blue, White, Gray, Clear



### Film

.0015" virgin polyethylene sheet coated with a non-transferable adhesive. Low density, low stretch and silicone-free.

### Adhesive

Non-transferable, water based silicone free acrylic copolymer with an added anti-microbial agent to inhibit possible bacterial growth. Adhesive level minimum of 9.5 ounces per square inch with stainless steel method per PSTC-1 (Pressure Sensitive Tape Council).

### Backing

Full coverage adhesive backing for adhering to the floor for use. Double-sided backing full width adhesive coated polyethylene film. Double-sided tape strips also available.

### Tabbing

Each sheet consecutively numbered with permanent and non-removable tab for soiled sheet removal. Tab consist of .001" mil high density, low stretch polyethylene.

### Construction

Each mat is created with exact dimensions as specified. All mats have square corners.

### Packaging

30 removable, peel-off sheets, 4 mats per case, 120 sheets per case. Packaged in a 200 lb. rated corrugated box sealed with a permanent boxing adhesive. Box is die-cut with a flat interior surface to prevent wrinkling and creasing of mat during shipping. All packaging materials are incinerable using standard procedures. Other put-ups are available.

### Application

For use before entering cleanrooms or controlled areas to remove foot borne particulate, including dirt, dust and other foreign debris.

Style	Size	Pack
P-101	18" x 36"	30 sheets/mat, 4 mats/case
P-102	18" x 45"	" "
P-103	36" x 36"	" "
P-104	36" x 45"	" "
P-105	26" x 45"	" "
P-107	36" x 60"	" "
P-108	36" x 72"	" "
P-111	24" x 36"	" "
P-112	24" x 45"	" "

Also, available in: 40 sheets/mat, 3 mats/case  
60 sheets/mat, 4 mats/case

### CONNECTICUT CLEAN ROOM CORPORATION

P.O. Box 840, 32 Valley Street, Bristol, CT 06011-0840

Phone: (860) 589-0049 • Fax: (860) 585-7355

[www.ctcleanroom.com](http://www.ctcleanroom.com)

